

Dirkoma P45

User Manual

Pinhole camera Dirkoma P45 is designed to use Sheet film or Photographic paper 4 x 5 in. Keep the device in a dry location and do not expose to strong wind and rainy weather beyond the necessary period for shooting. When handling the device, do not use violence and prevent ingress of dust and dirt into the hole.

Technical specifications:	Image Format	4x5"
	Focal length	73 mm
	Focal Ratio	180

Instructions of use: Inserting a film into the camera: Put Sheet film or Photographic paper into the cartridge and then insert the cartridge into the camera.

Shooting pictures: Place the device on a tripod or a solid surface. Brass pegs on the body show the frame edge. Loosen the lock screw of the shutter and by turning the shutter shoot the picture. After the exposure period, close the shutter and secure by tightening the screw. Determine the exposure time by calculating them for focal ratio of 180. Approximate time for ISO 100 is 10 to 15 seconds in direct sunlight, 15 to 30 seconds on cloudy day and 2 hours in the room with light coming through the windows.